



1. Vundamendi taldmiku alla kuni purunenud lubjakivini teha killustikalus, mis tasandada lahja betooniga 50mm.
2. Vundamendi seinad plokkidest Fibo5 mördil 50MPa ehitada vastvalt tootja juhistele.
3. Postvundamendid betoon C25/30.